

Report Date: 01 Feb 2013

Summary Report for Individual Task

031-COM-1035

Protect Yourself from Chemical And Biological (CB) Contamination Using Your Assigned Protective Mask

Status: Approved

DISTRIBUTION RESTRICTION: Distribution authorized to U.S. Government agencies and their contractors only based on the Technical Manual. This determination was made on 31 August 2010. Insert

AMSRD-ECB-ENA-ENA-L, 5183 Blackhawk Road, Aberdeen Proving Ground, MD 21010-5424.

DESTRUCTION NOTICE: Destroy by any method that will prevent disclosure of contents or reconstruction of the document

Condition: You are given your assigned protective mask, hood, carrier, a canteen with an M1 canteen cap or water canteen cap, and M8 detector paper. You find yourself in one of the following situations: 1) you hear or see a CB agent and/or unknown toxic industrial chemical attack/spill, 2) you realize, through other means, that you are under a CB agent and/or toxic industrial chemical attack, 3) you are ordered to mask, 4) you must enter a contaminated area, and 5) after having donned your protective mask, you need to drink from your canteen.

Standard: Protect yourself from CB agent and/or unknown toxic industrial chemical contamination by donning, clearing, and checking your assigned protective mask within 9 seconds without becoming contaminated. Drink water through your protective mask from your canteen without becoming a casualty.

Special Condition: Do not wear contact lenses when performing this task. Do not use masks with damaged filters because certain models contain hazardous materials. Do not change filter elements in a contaminated environment.

Special Standard: Note: The mask gives you immediate protection against traditional warfare agents. The mask may not be adequate to protect you from certain toxic industrial chemicals, but it provides the best available protection to enable you to evacuate the hazard area. You may be required to evacuate to a minimum safe distance of at least 300 meters upwind from the contamination (if possible) or as directed by the commander.

Special Equipment:

Safety Level: Low

MOPP:

Task Statements

Cue: If you hear or see a chemical or biological attack.

DANGER

None

WARNING

None

CAUTION

None

Remarks: None

Notes: Soldier must complete steps 1 through 4 within 9 seconds.

WARNING

Before donning and adjusting the mask, female warfighters will remove earrings, hair fasteners (hair clips, hair pins, combs, and rubber bands), hair knots, buns, or braids that will interfere with the mask seal and will let hair hang freely. When wearing the Ground Crew Ensemble, hair will be neatly tucked inside jacket. Facial hair could result in an improper mask fit resulting in illness or death.

Do not wear contact lenses (soft or hard) while wearing the masks. Inadequate oxygen supply to the corneal surface, and exposure to dust, dirt, and smoke or gas may cause serious vision loss or eye damage. Personnel requiring vision correction will use the optical inserts that have been provided to them with their protective masks.

1. Don the mask.

a. Stop breathing, and close eyes.

b. Remove helmet, put helmet between legs above knees or hold rifle between legs and place helmet on the muzzle. If helmet falls continue to mask.

c. Take off glasses, if applicable.

d. Open the mask carrier with left hand.

e. Grasp the mask assembly with right hand, and remove it from the carrier.

f. Place chin in the chin pocket, and press the facepiece tight against face.

Note: The temple and forehead straps have already been adjusted during fitting.

g. Grasp the tab and pull the head harness over the head. Ensure that the ears are between the temple straps and the cheek straps. Ensure that the head harness is pulled far enough over the head that the forehead straps are tight.

h. Use one hand to tighten the cheek straps, one at a time, while holding the head pad centered on the back of head with the other hand. Ensure that the straps lay flat against the head.

2. Clear the mask.

a. Seal the outlet disk valve by placing one hand over the outlet valve cover assembly.

b. Blow out hard to ensure that any contaminated air is forced out around the edges of the facepiece.

3. Check the mask.

a. Cover the inlet port of the filter canister or the inlet port of the armor quick disconnect with the palm of the hand, and inhale.

b. Ensure that the facepiece collapses against face and remains so while holding your breath, which indicates that the mask is airtight.

c. Remove any hair, clothing, or other matter between the face and the mask if the facepiece does not collapse to face.

d. Notify the chemical, biological, radiological, and nuclear (CBRN) noncommissioned officer (NCO) if the mask still does not collapse.

4. Resume breathing.

Note: There is no time standards for donning the hood.

5. Completes steps 1 through 4 within 9 seconds.

CAUTION

BE CAREFUL WHEN PULLING ON THE HOOD BECAUSE IT COULD SNAG AND TEAR ON THE BUCKLES OF THE HEAD HARNESS.

6. Secure the mask hood.

WARNING

Be careful not to break facepiece seal when pulling protective hood over your head.

a. For the M50/M51-series protective mask.

(1) Place hands up under the protective hood, stretch elasticized portion and raise protective hood up and over filters.

(2) Carefully pull excess protective hood material over head, neck and shoulders.

(3) Grasp underarm straps.

(4) Bring the male end of each underarm strap and fasten to female end.

(5) Tighten underarm straps.

b. For the M48 series protective mask.

(1) Carefully pull the back of the hood assembly over the head so hood covers the head, neck and shoulders.

(2) Tuck inner skirt inside the collar of the CBRN protective suit. This can be done using the buddy system.

c. For the M42- or M43-series protective mask, pull the hood over the head and zip the front closed to cover the bare skin.

d. For the M45-series protective mask, pull the M7 hood over the helmet and head so that the hood covers shoulders.

e. For the M40-series protective mask, don the hood so that it lies smoothly on the head.

(1) For masks equipped with the regular hood—

(a) Grasp the back edge of the hood skirt.

(b) Pull the hood completely over the head so that it covers the back of the head, neck, and shoulders.

(c) Zip the front of the hood closed by pulling the zipper slider downward.

(d) Tighten the draw cord.

(e) Secure the underarm straps by fastening and adjusting them.

(f) Close your mask carrier.

(g) Continue your mission.

(2) For masks equipped with the quick-doff hood—

(a) Place hands inside the hood and expand the elastic gathering around the neck of the hood.

(b) Stretch and carefully pull the hood over head so that the hood covers your head, neck and shoulders.

(c) Fasten the underarm straps.

(d) Put on the helmet.

Note: For combat vehicle crewman (CVC) helmet, perform the following steps: 1) disconnect the boom microphone from the helmet, 2) connect the mask microphone to the receptacle in the helmet, 3) grasp the helmet next to the ear cups with the hand, and spread the helmet as far as possible, 4) place the helmet over head, tilting the helmet forward slightly so that the first contact when putting it on is with the forehead surface of the mask and 5) rotate the helmet back and down over the head until it is seated in position.

(e) Close mask carrier.

(f) Continue the mission.

Note: If the Soldier is using the mask in conjunction with the joint-service, lightweight integrated suit technology (JSLIST), he/she skips this step (the mask lacks a hood because it is built in on the JSLIST).

WARNING

USE M8 DETECTOR PAPER TO CHECK FOR CONTAMINATION BEFORE USING THE DRINKING SYSTEM. IF CONTAMINATION IS DETECTED, DECONTAMINATE USING THE M295 DECONTAMINATION KIT. DO NOT CONNECT THE QUICK-DISCONNECT COUPLING TO YOUR CANTEEN UNTIL ALL SURFACES ARE FREE OF CONTAMINATION. CHEMICAL CONTAMINATION COULD ENTER YOUR MOUTH, AND YOU COULD BECOME A CASUALTY.

DO NOT BREAK THE MASK SEAL WHILE DRINKING FROM THE CANTEEN.

7. Drink water while wearing the mask.

a. Press in on the top of the outlet valve cover until the internal drink tube can be grasped between your teeth.

b. Steady the mask assembly with one hand and pull the quick-disconnect coupling out of the outlet valve cover. For the M50/M51 protective mask pull drink coupler out of coupler receptacle, below the front module.

c. Flip open the cover on the M1 canteen cap or open retaining strap on water canteen cap for the M50/M51 protective mask.

WARNING

IF RESISTANCE IS NOT FELT, YOUR DRINKING SYSTEM IS LEAKING. DO NOT DRINK. REPLACE YOUR CANTEEN. IF RESISTANCE IS STILL NOT FELT, NOTIFY YOUR CBRN NCO.

d. Push the quick-disconnect coupling into the canteen cap so that the pin enters the quick-disconnect coupling. For the M50/M51 protective mask push drink coupler into canteen cap so that seal snaps into the groove in the cap.

e. Turn drink tube lever on front module assembly upward, until it stops and is fully opened, to position internal drink tube in front of mouth, and grasp internal drink tube between your lips (for the M50/M51 and M48 protective mask only.)

WARNING

DO NOT TILT YOUR HEAD BACK WHILE DRINKING.

f. Blow to create positive pressure. You should feel some resistance.

g. Raise the canteen upside down and drink (if the system does not leak.)

h. Stop drinking after several swallows and lower the canteen. Blow into the internal drink tube to prevent the canteen from collapsing. Repeat the drinking procedure as required.

8. Doff the mask for storage.

a. M50/M51 protective mask

(1) Remove headgear.

(2) Loosen cheek straps completely by placing your thumbs behind the buckles and pulling forward so straps become loose. Grasp the front of the mask and lift it off your head.

(3) Replace headgear.

(4) Stow the audio frequency amplifier in the retaining loop located in the bottom of the mask carrier main stowage area before stowing the mask.

(5) Grasp the cheek straps and carefully pull the head harness over the front of the mask.

(6) Grasp the mask carrier flap tab and pull to open mask carrier flap.

(7) Grasp the mask by the front module assembly, place in mask carrier eyelens first, covered by head harness skullcap and face it away from the body.

b. M40A1 protective mask

(1) Remove helmet.

(2) Loosen cheek straps.

(3) Place one hand on the front voicemitter to hold mask assembly on face, with other hand grasp head harness tab, pull the head harness over the front of the mask assembly and remove mask assembly.

(4) Replace helmet.

(5) Pull head harness over front of mask assembly.

(6) Smooth the second skin/universal second skin over the front of the mask assembly.

(7) Pull the forehead straps tight over the second skin/universal second skin, by pulling the head harness down as far as possible, by pulling on the harness tab.

(8) Hold the facepiece assembly up and put it in the mask carrier with the lenses facing away from your body.

CAUTION

It is important to completely close the hook and pile fastener on the mask carrier cover. Failure to do this will result in collection of debris and damage to the mask assembly.

(9) Close the mask carrier. Seal the entire hook and pile fastener surface.

(10) Stowing M40A1/M42-Series Mask With Quick Doff Hood (QDH).

(a) Hold front of mask assembly in a horizontal position and smooth the QDH over it.

(b) Store the ends of the underarm straps in a "V".

(c) Fold the two edges of the QDH over the underarm straps to create a "V".

(d) Fold the "V" up to cover the eyelenses. Do not let the QDH cover the chin opening.

1 If stowing M42-series, wrap the two edges of the hood over the underarm straps and around the hose.

2 Grasp the hose through the hood and aligned hose to point down toward the chin.

CAUTION

To avoid damage to the mask assembly, DO NOT fold mask assembly when placing it in the mask carrier.

(e) Hold the facepiece assembly up and put it in the mask carrier with the lenses facing away from your body.

(f) Close the mask carrier. Seal the entire hook and pile fastener surface.

c. M43 protective mask

(1) Remove helmet.

(2) Detach canister disconnect along with canisters from top of blower. Let hose and canisters hang from facepiece.

(3) Turn blower off.

(4) Using both hands, gently lift hood up over head; let hood hang from front of facepiece.

(5) Loosen three head harness straps by rolling buckles forward.

(6) Grip head harness and pull facepiece up and off head.

(7) Check that the facepiece is dry and free of oil or solvents before stowing. If facepiece is not dry and free of oil or solvents, clean as directed.

(8) With hood hanging in front of facepiece, hold front of facepiece in a horizontal position (face down) and smooth the hood beneath it.

(9) Fold hood and microphone cable up around the back of facepiece.

(10) Open top flap on carrier.

(11) To stow the items in the proper locations proceed as follows:

(a) Place hose, canister disconnect and canisters into carrier section on the nametag side of the carrier.

(b) Place facepiece on top of canisters.

(c) Unsnap blower from harness.

(d) Insert blower with controls up, into carrier section on the back side of the carrier.

(e) Unclip shoulder, waist, leg straps and remove blower harness.

(f) Stow blower harness in carrier section with blower.

(g) Make sure technical manual is stowed in carrier section with blower.

(h) Close and seal top flap on carrier.

(i) Store carrier with contents in dark, dry location. Hang carrier by one of the straps for storage.

d. M45 protective mask.

(1) Remove helmet.

(2) Disconnect microphone (if issued) from helmet receptacle, then remove helmet.

(3) Loosen cheek straps ONLY.

(4) Place thumbs under both cheek tabs. Lift bottom of mask out and up over your head.

(5) Pull head harness over front of mask.

(6) With canister toward the bottom of the carrier, place mask in carrier with eyelenses facing up and away from body.

(7) Close carrier.

e. M48 protective mask

(1) Remove helmet.

(2) Using both hands, gently lift hood of facepiece assembly up over head; let hood hang from front of facepiece assembly.

(3) Loosen the three suspension harness straps by rolling buckles forward.

(4) Grip suspension harness and pull facepiece assembly up and off head.

(5) Turn blower assembly off.

WARNING

Any occurrences of redness, puffiness, or itchiness that persist for an extended period of time after removing the facepiece assembly should be referred to the flight surgeon for evaluation.

(6) Perform all After PMCS

(7) With hood assembly hanging in front of facepiece assembly, install facepiece assembly in facepiece carrier with open side of facepiece assembly toward the leg (back of facepiece carrier.)

(8) Tuck remainder of hood into facepiece carrier. Leave hose exposed from facepiece carrier.

(9) Close flap on facepiece carrier.

9. Perform all steps in sequence without becoming a casualty.

(Asterisks indicates a leader performance step.)

Evaluation Preparation: Setup: Evaluate this task during a field exercise or a tactical training session. Use a mask earlier fitted to the Soldier's face. The Soldier will bring his/her flight or CVC helmet. The Soldier should be in mission-oriented protective posture 4 (MOPP4). Do not use a new decontamination kit for every Soldier; use the kit as long as possible. Ensure that the Soldier has M8 detector paper in the mask carrier before testing.

Brief Soldier: Tell the Soldier to stand, while wearing his/her mask carrier containing his/her assigned protective mask with the hood attached. Provide the Soldier with one of the scenarios described in the conditions statement (cue to begin masking). Tell the Soldier to keep the mask on until you issue the all clear order. Tell the Soldier to drink water while wearing his/her assigned mask.

PERFORMANCE MEASURES	GO	NO-GO	N/A
1. Donned the mask.			
a. Stopped breathing and closed eyes.			
b. Removed helmet and placed helmet between legs (above knees) or held rifle between legs and placed helmet on the muzzle. If helmet falls continue to mask.			
c. Removed glasses, if applicable.			
d. Opened the mask carrier with one hand.			
e. Grasped the mask assembly with the other hand and removed it from the carrier.			
f. Placed chin in the chin pocket, and pressed the facepiece tight against the face.			
g. Grasped the tab and pulled the head harness over head. Ensured ears were between the temple straps and the cheek straps. Ensured that the head harness was pulled far enough over head so that the forehead straps are tight.			
h. Used one hand to tighten the cheek straps, one at a time, while holding the head pad centered on the back of head with the other hand. Ensured straps laid flat against head.			
2. Cleared the mask.			
a. Covered outlet valve cover with one hand.			
b. Blew out hard and forced any contaminated air out around the edges of the facepiece.			
3. Checked the mask.			
a. Covered the inlet port of the filter canister or the inlet port of the armor quick disconnect with the palm of your hand and inhale.			
b. Ensured facepiece collapsed against face and remained collapsed while holding breath.			
c. Removed hair, clothing or other matter between face and mask if the facepiece did not collapse on face.			
d. Notified chemical, biological, radiological, and nuclear (CBRN) noncommissioned officer (NCO) if the mask did not collapse.			
4. Resumed breathing.			
5. Completed steps 1 through 4 in sequence within 9 seconds.			
6. Secured the mask hood.			
a. M50/M51-series protective mask.			
(1) Placed hands up under the protective hood, stretched elasticized portion and raised protective hood up and over filters.			
(2) Pulled excess protective hood material over head, neck, and shoulders.			
(3) Grasped underarm straps.			
(4) Secured male end of each underarm strap to female end.			
(5) Tightened underarm straps.			
(6) Closed mask carrier.			
b. M48 series protective mask.			
(1) Pulled the back of the hood assembly over the head so hood covered the head, neck, and shoulders.			
(2) Tucked inner skirt inside the collar of the CBRN protective suit. Used the buddy system.			
c. M42- or M43-series protective mask, pulled the hood over head and zipped the front closed to cover all bare skin.			
d. M45-series protective mask, pulled hood over helmet and head so the hood covered the shoulders.			
e. M48 series protective mask.			
f. M40-series protective mask, don the hood so that it lies smoothly on the head.			
(1) For masks equipped with the regular hood—			
(a) Grasp the back edge of the hood skirt.			

(b) Pulled hood completely over the head so that it covered the back of the head, neck, and shoulders.			
(c) Zipped the front of the hood closed by pulling the zipper slider downward.			
(d) Tightened the draw cord.			
(e) Secured the underarm straps fastened and adjusted them.			
(f) Continued the mission.			
(2) For masks equipped with the quick-doff hood—			
(a) Placed hands inside the hood and expanded the elastic gathering around the neck of the hood.			
(b) Stretched and pulled the hood over the head so the hood covered the head, neck and shoulders.			
(c) Fastened the underarm straps.			
(d) Put on the helmet.			
(e) Closed mask carrier.			
(f) Continued the mission.			
7. Consumed water while wearing the mask.			
a. Pressed the top of the outlet valve cover and grasped the internal drinking tube between your teeth.			
b. Steadied the mask assembly with one hand and removed the quick-disconnect coupling from the outlet valve cover. Pulled drink coupler out of coupler receptacle, below the front module for the M50/M51 protective mask.			
c. Opened the cover on the M1 canteen cap or retaining strap on water canteen cap for the M50/M51 protective mask.			
d. Pushed the quick-disconnect coupling into the canteen cap so that the pin entered the quick-disconnect coupling. Pushed drink coupler into canteen cap so the seal snapped into the groove in the cap for the M50/M51 protective mask.			
e. Turned drink tube lever on front module assembly upward, until it stopped and was fully opened, and positioned internal drink tube in front of mouth, and grasped internal drink tube between lips (M50/M51 and M48 protective mask only.)			
f. Blew into canteen and created positive pressure.			
g. Raised the canteen upside down and consumed water.			
h. Stopped drinking after several swallows and lowered canteen. Blew into the internal drink tube and prevented the canteen from collapsing. Repeated drinking procedure as required.			
8. Doffed the mask for storage.			
a. M50/M51 Mask			
(1) Removed headgear.			
(2) Loosened cheek straps, placed thumbs behind the buckles and pulled forward so straps became loose. Grasped the front of the mask and lifted it off head.			
(3) Replaced headgear.			
(4) Stowed audio frequency amplifier in the retaining loop located in the bottom of the mask carrier main stowage area before stowing the mask.			
(5) Grasped the cheek straps and pulled the head harness over the front of the mask.			
(6) Grasped the mask carrier flap tab and pulled open the mask carrier flap.			
(7) Grasped the mask by the front module assembly and placed in mask carrier, eyelens first, covered by head harness skullcap, and faced away from the body.			
b. M40A1 Mask.			
(1) Removed helmet.			
(2) Loosened cheek straps			
(3) Placed one hand on the front voicemitter to hold mask assembly on face, with the other hand grasped head harness tab, pulled the head harness over the front of the mask assembly and removed mask assembly.			
(4) Replaced helmet.			

(5) Pulled head harness over front of mask assembly.			
(6) Smoothed the second skin/universal second skin over the front of the mask assembly.			
(7) Pulled the forehead straps tight over the second skin/universal second skin and pulled the head harness down as far as possible by pulling on the harness tab.			
(8) Held the facepiece assembly up and placed it in the mask carrier with the lenses facing away from the body.			
(9) Closed the mask carrier. Sealed the hook and pile fastener surface.			
(10) Stowed M40A1/M42-Series Mask With Quick Doff Hood (QDH).			
(a) Held front of mask assembly in a horizontal position and smoothed the QDH over it.			
(b) Stored the ends of the underarm straps in a "V."			
(c) Folded the two edges of the QDH over the underarm straps to create a "V."			
(d) Folded the "V" up to cover the eyelenses. Did not allow the QDH cover the chin opening.			
1 If stowing M42-series, wrapped the two edges of the hood over the underarm straps and around the hose.			
2 Grasped the hose through the hood and aligned hose to point down toward the chin.			
(e) Held the facepiece assembly up and placed it in the mask carrier with the lenses facing away from the body.			
(f) Closed the mask carrier. Sealed the hook and pile fastener surface.			
c. M43 protective mask			
(1) Removed headgear.			
(2) Detached canister disconnect along with canisters from top of blower. Allowed hose and canisters to hang from facepiece.			
(3) Turned blower off.			
(4) Used both hands, lifted hood up over head; allowed hood to hang from front of facepiece.			
(5) Loosened the three head harness straps and rolled the buckles forward.			
(6) Gripped head harness and pulled facepiece up and off head.			
(7) Checked that facepiece was dry and free of oil or solvents before stowing. If facepiece was not dry and free of oil or solvents, cleaned as directed.			
(8) With hood hanging in front of facepiece, held front of facepiece in a horizontal position (face down) and smoothed the hood beneath it.			
(9) Folded hood and microphone cable up around the back of facepiece.			
(10) Opened top flap on carrier.			
(11) Stowed items in the proper locations as followed:			
(a) Placed hose, canister disconnect, and canisters into carrier section on the nametag side of the carrier.			
(b) Placed facepiece on top of canisters.			
(c) Unsnapped blower from harness.			
(d) Inserted blower with controls up, into carrier section on the back side of the carrier.			
(e) Unclipped shoulder, waist, and leg straps and removed blower harness.			
(f) Stowed blower harness in carrier section with blower.			
(g) Ensured technical manual was stowed in carrier section with blower.			
(h) Closed and sealed top flap on carrier.			
(i) Stored carrier with contents in dark, dry location. Hung carrier by one of the straps for storage.			
d. M45-series protective mask.			
(1) Removed headgear.			
(2) Disconnected microphone (if issued) from helmet receptacle and removed helmet.			

(3) Loosened cheek straps ONLY.			
(4) Placed thumbs under both cheek tabs. Lifted bottom of mask out and up over head.			
(5) Pulled head harness over front of mask.			
(6) With canister toward the bottom of the carrier, placed mask in carrier with eyelenses facing up and away from body.			
(7) Closed carrier.			
e. M48 protective mask			
(1) Removed headgear.			
(2) With both hands, gently lifted hood of facepiece assembly up over head; allowed hood to hang from the front of facepiece assembly.			
(3) Loosened the three suspension harness straps by rolling buckles forward.			
(4) Gripped suspension harness and pulled facepiece assembly up and off head.			
(5) Turned blower assembly off.			
(6) Checked that the facepiece assembly was dry and free from oil and solvents before stowing. If facepiece assembly was dirty, cleaned as directed.			
(7) With hood assembly hanging in front of facepiece assembly, installed facepiece assembly in facepiece carrier with open side of facepiece assembly toward the leg (back of facepiece carrier).			
(8) Tucked remainder of hood into facepiece carrier. Left hose exposed from facepiece carrier.			
(9) Closed flap on facepiece carrier.			
9. Performed all steps in sequence without becoming casualty.			

Supporting Reference(s):

Step Number	Reference ID	Reference Name	Required	Primary
	FM 3-11.3	Multiservice Tactics, Techniques, and Procedures for Chemical, Biological, Radiological, and Nuclear Contamination Avoidance	Yes	No
	FM 3-11.4	Multiservice Tactics, Techniques, and Procedures for Nuclear, Biological, and Chemical (NBC) Protection	Yes	No
	TM 3-4240-300-10-2	OPERATORS MANUAL FOR CHEMICAL-BIOLOGICAL MASK: COMBAT VEHICLE, M42 (NSN 4240-01-258-0064) SMALL, (4240-01-258-0065) MEDIUM, (4240-01-258-0066) LARGE (REPRINTED W/BASIC INCL C1-3)D O	Yes	No
	TM 3-4240-312-12&P	OPERATORS AND UNIT MAINTENANCE MANUAL FOR MASK, CHEMICAL-BIOLOGICAL: AIRCRAFT, M43, TYPE I (NSN 4240-01-208-6966) SMALL, (4240-01-208-6967) MEDIUM, (4240-01-208-6968) LARGE, (4240-01-208-6969) EXTRA LARG	No	No
	TM 3-4240-346-10	OPERATORS MANUAL FOR CHEMICAL-BIOLOGICAL MASK: FIELD, M40A1 (NSN 4240-01-370-3821-SMALL) (4240-01-370-3822-MEDIUM) (4240-01-370-3823-LARGE); CHEMICAL-BIOLOGICAL MASK: COMBAT VEHICLE, M42A2 (4240-01-4100	Yes	No
	TM 3-4240-542-13&P	"Operator and Field Maintenance Manual for Mask, Chemical-Biological: Joint Service General Purpose, Field, M50 PURPOSE, FIELD, M50"	Yes	No

Environment: Environmental protection is not just the law but the right thing to do. It is a continual process and starts with deliberate planning.

Always be alert to ways to protect our environment during training and missions. In doing so you will contribute to the sustainment of our training resources while protecting people and the environment from harmful effects.

Safety: In a training environment, leaders must perform a risk assessment in accordance with FM 5-19, Composite Risk Management. Leaders will complete a DA Form 7566 COMPOSITE RISK MANAGEMENT WORKSHEET during the planning and completion of each task and sub-task by assessing mission, enemy, terrain and weather, troops and support available-time available and civil considerations, (METT-TC). Note: During MOPP training, leaders must ensure personnel are monitored for potential heat injury. Local policies and procedures must be followed during times of increased heat category in order to avoid heat related injury. Consider the MOPP work/rest cycles and water replacement guidelines IAW FM 3-11.4, NBC Protection, FM 3-11.5, CBRN Decontamination. Everyone is responsible for safety. A thorough risk assessment must be completed prior to every mission or operation.

Prerequisite Individual Tasks : None

Supporting Individual Tasks :

Task Number	Title	Proponent	Status
130-LDAC-4428	CBRN Protective Mask Confidence Exercise	130 - Cadet Command	Analysis
031-COM-1036	Maintain Your Assigned Protective Mask	031 - CBRN (Individual)	Approved
031-503-2009	Conduct Protective Mask Fitting	031 - CBRN (Individual)	Approved
130-LDAC-1035	Protect Yourself from Biological and Chemical Contamination Using your Assigned protective mask	130 - Cadet Command	Analysis
031-xxx-1063	Conduct Protective Mask Fitting	031 - CBRN (Individual)	Analysis

031-COM-1042	Protect Yourself from CBRN Injury/Contamination when Changing MOPP using the JSLIST Chemical-Protective Ensemble.	031 - CBRN (Individual)	Approved
031-627-3036	Identify Components of an Improvised Chemical or Biological (CB) Weapons Lab	031 - CBRN (Individual)	Approved

Supported Individual Tasks :

Task Number	Title	Proponent	Status
071-001-0005	Operate the Chemical, Biological, Radiological and Nuclear (CBRN) System on an M2A3/M3A3 Bradley Fighting Vehicle (BFV)	071 - Infantry (Individual)	Approved
031-503-1040	Protect Yourself from CBRN Injury/Contamination with the JSLIST Chemical-Protective Ensemble	031 - CBRN (Individual)	Analysis
031-COM-1019	React to Chemical or Biological (CB) Hazard/Attack	031 - CBRN (Individual)	Approved
031-COM-1040	Protect Yourself from CBRN Injury/Contamination with the JSLIST Chemical-Protective Ensemble	031 - CBRN (Individual)	Approved
031-COM-1013	Decontaminate Yourself and Individual Equipment Using Chemical Decontaminating Kits	031 - CBRN (Individual)	Approved

Supported Collective Tasks :

Task Number	Title	Proponent	Status
03-6-0071	Respond to a Chemical Agent Attack	03 - CBRN (Collective)	Approved
03-2-9201	Implement CBRN Protective Measures	03 - CBRN (Collective)	Approved
03-6-0070	Prepare for a Chemical Attack	03 - CBRN (Collective)	Approved
03-3-0047	Conduct CBRN Dismounted Reconnaissance - Sampling	03 - CBRN (Collective)	Approved
03-3-0044	Conduct CBRN Dismounted Reconnaissance - Locate	03 - CBRN (Collective)	Approved
03-4-0019	Respond to a Biological Attack	03 - CBRN (Collective)	Approved
03-5-0012	Conduct a CBRNE Sensitive Site Exploitation	03 - CBRN (Collective)	Approved
03-3-5123	Perform Thorough Decontamination	03 - CBRN (Collective)	Approved
03-3-5127	Conduct a CBRN Survey	03 - CBRN (Collective)	Approved
03-2-9224	Conduct Operational Decontamination	03 - CBRN (Collective)	Approved
03-2-9225	Conduct a Chemical Reconnaissance	03 - CBRN (Collective)	Approved
03-3-0045	Conduct CBRN Dismounted Reconnaissance - Survey or Marking	03 - CBRN (Collective)	Approved
03-2-9226	Cross a Chemically Contaminated Area	03 - CBRN (Collective)	Approved
03-5-6595	Conduct CBRN Assessments	03 - CBRN (Collective)	Approved
03-5-6596	Conduct CBRN Analytical Mission	03 - CBRN (Collective)	Approved
03-2-9203	React to a Chemical or Biological (CB) Attack	03 - CBRN (Collective)	Approved

ICTL Data :

ICTL Title	Personnel Type	MOS Data
Warrior Tasks and Battle Drills	Enlisted	MOS: 000, Skill Level: SL1
Battlefield Weather Course (BWC) (6 Sep 12)		