



MC6/T-11 ATPS FIT CRITERIA



To achieve the proper fit, jumpers must don the MC6 and T-11 using the correct procedures. Evaluate your jump buddy to ensure:



1. The Canopy Release Assemblies are resting in the hollow of the jumper's shoulders below the collarbone

Jumper Action #2 - Secure the Chest Strap by incorporating a two (2) to three (3) finger quick release. Secure the quick release and the free running end in their Webbing Retainers with the Tabbed Portion facing towards the Chest Strap Friction Adapter. The Chest Strap and Main Lift Webs should form the shape of a "H" not (-) or)-(

Jumper Action #4 - Secure the "D" rings by inserting the thumbs of each hand from bottom to top; pull downward and standing erect



2. The Saddle is routed around the meaty portion of the jumper's thighs **NOT** the buttocks.

Buddy Action #2 - Lower the "L" Shaped Ejector Snap Pads by extending the Horizontal Back strap from the upper portion of the Ejector Snap

Jumper Action #3 - Pull the Ejector Snaps and "L" Shaped Ejector Snap Pads as far forward as possible while ensuring that the Saddle is routed underneath the hamstrings ; **NOT THE BUTTOCKS**

Maintain a modified "High Jumper position" while securing the Kit Bag

Secure the Leg Straps ensuring that the Leg Straps are properly routed through the Leg Strap Retainers or exposed Carrying Handle; and "S" fold, accordion fold



3. The top edge of the pack tray does not fall below the jumper's shoulders

Buddy Action #3 - Remove all slack from the Horizontal Back Strap by simultaneously pulling up on both sides of the Horizontal Back Strap where it emerges from the Main Lift Webs. **DO NOT EXECUTE UNTIL JUMPER IS STANDING ERECT**

Jumper Action #5 - Remain standing erect, release the "D" rings and apply pressure to the Horizontal Back Strap just above the Ejector Snaps when a tight but not uncomfortable adjustment has been made

Buddy Action #4- Remove all slack on each side by placing one hand on top of the Diagonal Back Strap while tightening down the free running end of the Horizontal Back Strap with the other. "S" fold, accordion fold, or roll the free running ends and secure in the Webbing Retainers